

RAE Systems, Inc.

RAE Systems, Inc. Telephone 408-752-0723 1339 Moffett Park Dr. Tube Orders 1-888-723-8823 Telephone 408-752-0723 Sunnyvale, CA 94089 USA Web www.raesystems.com

## Gas Detection Tube Data Sheet Hydrogen Sulfide H<sub>2</sub>S No. 10-103-40

	Extended Range	Standard Range	Extended Range
Range (ppmv)	0.05 - 1%	0.1 - 2%	0.2 - 4%
No. of Pump Strokes	2	1	0.5
Sample Volume (mL)	200	100	50
Sample Time (min)	2 x 2	2	1.5
Correction Factor	0.5	1	2

Precision (Relative Standard Deviation)\*: ≤ ± 10%

Linearity with No. of Pump Strokes:  $r^2 = 0.998$ 

Humidity: No effect 5 - 85% RH

Temperature Range: 0 - 40°C

(32 - 104°F)

Temp (°C/°F)	0/32	18/64	25/77	40/104
Corr. Factor	1.2	1.1	1.0	1.0

Storage Life: 2 years in darkness at 5 - 25°C (40 - 77°F). Refrigeration preferred.

Color Change: Light Blue → Black

Reaction Principle: H<sub>2</sub>S + CuSO<sub>4</sub> → CuS + H<sub>2</sub>SO<sub>4</sub>

Cross-sensitivity: Substance	Concentration (ppmv)	Apparent Reading*
СО	3000	0
CH <sub>4</sub>	25000	0
NO	100	0
NO <sub>2</sub>	200	0
NH <sub>3</sub>	300	0
SO <sub>2</sub>	20	0
Methyl mercaptan	0.1%	0.1%#
Diethyl sulfide	1000	0
Isobutylene	100	0
Toluene	100	0
Hexane	1200	0

<sup>\*</sup>Data based on RAE pumps and tubes used in standard range.

<u>Caution</u>: Dispose of spent or expired tubes according to local regulations. Possibly hazardous materials are given under the section Reaction Principle.

<sup>\*</sup>Concentrations in the high % range leave a yellow color over the entire tube.

Other Possible Interferences: High Concentrations of ammonia; NO<sub>2</sub> in mixtures.

No response to CS<sub>2</sub>.